

Questions & Answers
Tucker Property
COMM # 54935-4831-54
BRRTS #03-20-535343

QUESTIONS:

- 1) It appears that MW300 will get destroyed during the excavation project. Do you want it reinstalled?

A.) MW-300 needs to be abandoned prior to excavation. It will be replaced with a sump.
- 2) In which of the 3 excavation areas do you want the 2 sumps installed?

A.) There are only two excavation areas.
- 3) Are the sumps to be installed as the excavation is backfilled? As a drilling project?

A.) Either way is OK.
- 4) What diameter should the sumps be?

A.) 4 inch will be OK
- 5) Do you have a preference on screen length and depth?

A.) 6 ft length set at the lowest point of each excavation.
- 6) What are the excavation sidewall samples to be analyzed for?

A.) PVOCs + Naphthalene